Before You Start

A Tapo Hub is required. Make sure your Tapo Hub is successfully added via the Tapo app.







1 Power Up Your Sensor

Remove the battery insulation tab to power up your sensor. The LED should blink.

Note: If the LED is not blinking, refer to the reverse side for reset




2 Set Up Your Sensor

Open the Tapo app and tap the \oplus button. Select **Sensors** and then your model. Follow the app instructions to complete setup.




3 Test Your Sensor


Take your sensor to the preferred location and wave your hand in front of the sensor to test it. The Tapo app should show if the sensor is triggered.




4 Place Your Sensor

Option 1: Magnetically attach to metallic objects





Adhesive





Option 3:

Place it on a shelf

! Detection Area


The sensor should be aligned with the detection area and placed as close as possible to the edge of a table or cabinet. The installation height should not be higher than 2 meters.






Meet Your Motion Sensor

The Motion Sensor detects movement in a certain area and triggers different actions in response. This makes your home safer and smarter.



How to replace the battery



How to reset your sensor

Use a pin to press and hold the Reset button for 5 seconds until the front LED starts blinking.





Need some help?

Visit www.tapo.com/support/ for technical support, user guides, FAQs, warranty & more



Do not attempt to disassemble, repair, or modify the device. If you need service,

please contact us.

Do not use the device where wireless devices are not allowed.

Do not ingest battery. Chemical Burn Hazard

We cannot guarantee that no accidents or damage will occur due to improper u of the device. Please use this product with care and operate at your own risk



This product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

If the battery compartment does not close securely, stop using the product and keep

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

of a battery, that can result in an explosion. can result in an explosion or the leakage of flammable liquid or gas: Do not leave a

leakage of flammable liquid or gas.

For EU/UK Region:

Operating Frequency / Nominal Operating Frequency / Max Output Power:

863~865MHz / 863.35MHz / 25mW (e.r.p)

863~865MHz / 864.35MHz / 25mW (e.r.p) 868~868.6MHz / 868.35MHz / 25mW (e.r.p)

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU. 2009/125/EC.

2011/65/EU and (EU) 2015/863.

The original EU declaration of conformity may be found at

https://www.tapo.com/en/support/ce/


The original UK declaration of conformity may be found at https://www.tapo.com/support/ukca/



Quick Start Guide

Smart Motion Sensor







7106509752 REV1.2.1 Images may differ from actual products.